Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386



Flow Transmitter LABO-VHZ-I / U / F / C



- Volumetric flow measurement
- Almost no effect from differing viscosities
- 0..10 V, 4..20 mA , frequency/pulse output, completely configurable
- Robust construction
- Compact design

Characteristics

The VHZ gearwheel flow meter measures the flow by a volumetric principle, in which a pair of gearwheels is moved proportional to the flow rate. The movement of the gearwheels is measured through the enclosing housing wall by a sensor. The devices are suitable for viscous, fluid, self-lubricating media, as well as for aqueous fluids such as soaps, pasts, emulsions etc. which have a non-abrasive character. Because of the volumetric functioning principle, the devices are almost completely independent of viscosity.

The LABO electronics make various output signals available:

- Analog signal 0/4..20 mA (LABO-VHZ-...I)
- Analog signal 0/2..10 V (LABO-VHZ-...U)
- Frequency signal (LABO-VHZ-...F) or
- A value signal Pulse / x Litres (LABO-VHZ-...C)

A model with switching output is also available.

If desired, the range end value can be set to the currently existing flow using "teaching".

Sensor gearwheel volumeter Nominal width DN 8..25 Process female thread G ¹/₄..G 1 connection 0.02..150 l/min for details, see table "Ra Measurement ±3 % of the measured v accuracy in the specified metering (measured at 20 mm²/s) Repeatability ±0.3 % Medium -25..+80 °C temperature optionally -25..+120 °C Ambient -20..+77 °C temperature "Pressure resistance an Pressure loss see upstream page "Full

Technical data

Process	female thread G ¹ / ₄ G 1	
connection		
Metering ranges	0.02150 l/min	
	for details, see table "Ranges"	
Measurement	± 3 % of the measured value	
accuracy	in the specified metering range	
	(measured at 20 mm²/s) ±0.3 %	
Repeatability		
Medium	-25+80 °C	
temperature Ambient	optionally -25+120 °C -20 +70 °C	
temperature	-20+70 C	
Pressure	see table	
resistance	"Pressure resistance and weight"	
Pressure loss	see upstream page "Function and	
i i occure i occ	benefits - volumetric, gearwheel"	
Materials	see table "Materials"	
medium-contact		
Materials, non-	Sensor tube CW614N nickelled	
medium-contact	Adhesive Epoxy resin	
	Flange bolts stainless steel	
Supply	1030 V DC at voltage output 10 V:	
voltage	1530 V DC	
Power	< 1 W (for no-load outputs)	
consumption		
Output data:	all outputs are resistant to short circuits and reversal polarity protected	
Current	420 mA (020 mA available on request)	
output:		
Voltage	010 V (210 V available on request)	
output:	output current max. 20 mA	
Frequency	transistor output "push-pull"	
output:	I _{out} = 100 mA max.	
Pulse output:	transistor output "push-pull"	
	I _{out} = 100 mA max.	
	pulse width 50 ms	
Dianlay	pulse per volume is to be stated	
Display	yellow LED indicates operating voltage (LABO-VHZ-I / U) or	
	output status (LABO-VHZ-F / C)	
	(rapid flashing = Programming)	
Electrical	for round plug connector M12x1, 4-pole	
connection		
Ingress protection	IP 67	
Weight	see table "Connection, pressure resistance,	
	and weight"	
Conformity	CE	

senseca

LABO-VHZ-I / U / F / C

Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386

senseca


LABO-VHZ-I / U / F / C


Product Information Signal output curves

Value x = Begin of the specified range = not specified range


Current output







Frequency output



fmax selectable in the range of up to 2000 Hz

Other characters on request.

Pressure resistance and weight

G	Types	PN	Housing material	Weight
		bar		kg
G ¹ / ₄	LABO-VHZ-008GA	200	Aluminium	0.5
G ¹ / ₄	LABO-VHZ-008GK	160	Stainless steel	1.5
G ³ / ₈	LABO-VHZ-010GA	160	Aluminium	0.5
G ³ / ₈	LABO-VHZ-010GK	160	Stainless steel	1.5
G ³ / ₄	LABO-VHZ-020GA	160	Aluminium	1.6
G ³ / ₄	LABO-VHZO-020GA	100	Aluminium / glass	1.6
G 1	LABO-VHZ-025GA	80	Aluminium	6.3


Ranges

Metering range	Types	Pulse volume (= resolution)	
l/min		cm ³	
0.02 2	LABO-VHZ-008	0.04	
0.10 6	LABO-VHZ-010	0.20	
0.50. 50	LABO-VHZ(O)-020	2.00	
3.00 150	LABO-VHZ-025	5.22	

Materials

	LABO-VHZ- 008025GA	LABO-VHZ- 008GK	LABO-VHZ- 010025GK
Housing	Al anodised	stainless steel 1.4404	stainless steel 1.4404
gear- wheel and Axis	stainless steel 1.4462	stainless steel 1.4462	stainless steel 1.4462
Bearing	iglidur X	stainless steel 1.4037 / 1.4016 /PVD-coated	iglidur X
Seal	FKM	FKM	FKM
Sight glass	glass (only with VHZO)		

Wiring



Connection example: PNP NPN



Before the electrical installation, it must be ensured that the supply voltage corresponds to the data sheet.

It is recommended to use shielded wiring.

The push-pull output) of the frequency or pulse output version can as desired be switched as a PNP or an NPN output.

Senseca Germany GmbH Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386


senseca LABO-VHZ-I / U / F / C

M12x1

Product Information

Dimensions


LABO-VHZ-008




• ≈ 109 68 23 90 69 12 S \oplus 25 29, 06 50 G3/4 ø36 Ø11 5 ģ18


LABO-VHZ-025


LABO-VHZ-020





LABO-VHZ-010





Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386

Product Information

Handling and operation

Installation

The VHZ flow measurement device can be installed anywhere in the pipework system. A run-in section is not required. The direction of flow may be freely chosen.

It should be ensured that no dirt particles (thread cutting swarf) can get into the flow space, as this could cause the blockage of the gearwheels. It may therefore be necessary to install filters upstream of the flow measurement device (mesh size $30 \mu m$).

Note

The metering range end value can be programmed by the user via "teaching". Requirement for programmability must be stated when ordering, otherwise the device cannot be programmed. The ECI-1 device configurator with associated software is available as a convenient option for programming all parameters by PC, and for adjustment.

The teaching option is not available for the pulse output version.

Operation and programming

- The teaching process can be carried out by the user as follows:
- The flow rate to be set is applied to the device.
- Apply an impulse of at least 0.5 seconds and max. 2 seconds duration to pin 2 (e.g. via a bridge to the supply voltage or a pulse from the PLC), in order to accept the measured value.
- When the teaching is complete, pin 2 should be connected to 0 V, so as to prevent unintended programming.

The devices have a yellow LED which flashes during the programming pulse. During operation, the LED serves as an indicator of operating voltage (for analog output) or of switching status (for frequency or pulse output).


In order to avoid the need to transit to an undesired operating status during the teach-in, the device can be provided ex-works with a teach-offset. The teach-offset point is added to the currently measured value before saving. The offset point can be positive or negative.

Example: The end of the metering range should be set to 80 %. However, only 60 % can be achieved without problem. In this case, the device would be ordered with a "teach-offset" of +20 %.. At a flow rate of 60 % in the process, teaching would then store a value of 80 %.

There are many more parameters which can be programmed by the ECI-1 device configurator if necessary.

Ordering code

The base device is ordered, e.g. VHZ-008GA002E with electronics, e.g. OMNI-VHZ-008IPLO $\ensuremath{\mathsf{VHZ}}$



O=Option

	puon			
1.	Sight glass			
	-	no sight glass		
	0-	with sight glass		
2.	Nomina	al width		
	008	DN 8 - G ¹ / ₄		•
	010	DN 10 - G ³ / ₈		•
	020	DN 20 - G ³ / ₄	٠	•
	025	DN 25 - G 1		•
3.	Proces	cess connection		
	G	female thread		
4.	Body material			
	А	aluminium • • • •		
	K C	stainless steel		
5.	Ranges	5		
	002	0.02 2 l/min		
	006	0.10 6 l/min		
	050	0.50 50 l/min •		
	150	3.00150 l/min •		
6.	Conne	ction for		
	E	electronics • • • •		
7.	For base device			
	008	VHZ-008GE		
	010	VHZ-010GE		
	020	VHZ(O)-020GE		
	025	VHZ-025GE		
8.	Signal	output		
	1	current output 420 mA		
	U	voltage output 010 V		
	F frequency output			
	С	pulse output		
9.	Programming			
	N	cannot be programmed (no teaching)		
	P O programmable (teaching possible)			
10.				
	S	for round plug connector M12x1, 4-pole		
11.				
	но	medium temperature max. 120 °C		
		(with 300 mm cable)		



Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386

s

Product Information

Required ordering information

Required ordering information	
For LABO-VHZF: Output frequency at full scale Maximum value: 2.000 Hz	Hz
For LABO-VHZC: The volume must be specified for the puls numerical value and unit) which will correspo	
Volume per pulse (numerical value)	
Volume per pulse (unit)	
Options	
Special range for analog output: <= metering range (standard=metering range)	l/min
Special range for frequency output:	l/min

<= metering range (standard=metering range)

Power-On delay period (0..99 s)

(time after applying power during which the outputs are not activated or set to defined values)

Further options available on request.

Accessories

- Cable/round plug connector (KB...) • see additional information "Accessories"
- **Evaluation electronics OMNI-TA**
- Device configurator ECI-1 .

