Senseca Germany GmbH

Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386




Product Information

Flow Switch G-...GR




Dimensions and weights

G	Types	X
G ¹ / ₄	G-008	12
G ³ / ₈	G-010	
G ¹ / ₂	G-015	13



optionally DIN 43650-A / ISO 4400 plug



Handling and operation

- Include straight calming section of 5 x DN in inlet and outlet.
- If the media are dirty, install a filter (use magnetic filter for ferritic components).
- It must be ensured that the values given for voltage, current, and power are not exceeded.
- When switched on, a load must be connected in series. The electrical details apply to ohmic loads. Capacitive, inductive and lamp loads must be operated using a protective circuit.

- Adjusted switching value
- Small switching point

Characteristics

Balls fitted with magnets rise in proportion to the flow against the magnetic force of an opposite-poled magnet and actuate a reed contact.

Technical data

Switch	reed switch
Nominal width	DN 815
Process	female thread G ¹ / ₄ G ¹ / ₂
connection	
Adjustment range	0.150.4 l/min horizontal inwards flow with
	decreasing flow rate
Q _{max.} recommended	G ¹ / ₄ - 4 l/min
	G ³ / ₈ - 8 l/min
	G ¹ / ₂ - 12 l/min
Tolerance	±10 % of full scale value
Pressure	PN 16 bar
resistance	
Medium	-20+80 °C
temperature	
Ambient	-20+70 °C
temperature	
Media	water (oils up to 20 mm²/s, and gases on request)
Wiring	normally closed (n.c.) no. 0.214 =
Switching voltage	max. 250 V AC
Switching current	max. 1 A
Switching	max. 50 VA
capacity	
Protection class	1 - PE connection
Ingress protection	IP 65
Electrical	Standard: cable screw gland Pg 11,
connection	optionally DIN 43650-A / ISO 4400 plug
Materials	Rg 5 nickelled, CW614N nickelled, POM,
medium-contact	Klingersil C-4400, hard ferrite
Non-medium-	CW614N, NBR
contact materials	
Weight	0.6 kg
Installation	Standard: horizontal inwards flow;
location	switching head upwards

Senseca Germany GmbH


Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386



Product Information

Ordering code

Standard device



A Newsinel width

1.	Nominal width	
	800	DN 8-G ¹ / ₄
	010	DN 10 - G ³ / ₈
	015	DN 15 - G ¹ / ₂
	Process connection	
2.	Process of	connection
2.	Process o G	connection
2. 3.	G	

Options

- Transformer
- Adjustment for oil or gas
- Special values

Ordering information

- Specify direction of flow, medium, and switching point.
- For oils, state viscosity, temperature and designation (e.g. ISO VG 68) (enquire about range).
- For gases, state pressure (relative or absolute), temperature and medium (e.g. air) (enquire about range).