Senseca Germany GmbH

Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386




TS32

Product Information

T-pieces TS32





Features

The T-pieces are intended for use with flow transmitters of the series RRI-032/RRH-032.

The flow conditions in a T-piece are, by nature, less favourable than in a straight pipeline.

Several influential factors converge here:

- Expansion of the flow cross-section within the T-piece
- Undefined edges of pipe ends upstream and downstream from the measuring point .
 - Unknown inner diameter of connected pipelines
- Variable screw-in depth of connected pipelines

The flow pattern at the measuring point, therefore, is only conditionally predictable.

However, T-pieces can be used advantageously for applications with low requirements on reproducibility and stability:

- Available for metal pipelines with diameter DN32 or higher
- Installation is possible with ordinary tools (no boring or • welding necessary).

Technical data

Nominal widths	DN32, D	DN32, DN40, DN50			
Wetted materials	Body	Cast iron (DN32) or Red bronze (DN40/DN50)			
	Port	Brass nickel-plated			
Compressive strength	PN10				

Ordering code	Nominal size	G	В	н
TS32-032M	DN32	1 1/4"	90 mm	approx. 138 mm
TS32-040M	DN40	1 1/2"	108 mm	approx. 142 mm
TS32-050M	DN50	2"	122 mm	approx. 145 mm

Dimensions and ordering code