senseca

Product Information

Flow Transmitter



- Uncomplicated measurement of flow rates
- No magnets; uses inductive sensor
- Long working life thanks to high quality ceramic axis and special plastic bearing
- Run-in and run-out sections are not necessary.
- Modular construction with various connection systems
- Plug-in and rotatable connections
- Output signal PNP or NPN o.C.
- Intrinsically safe behaviour
- Optionally, non-return valve, filter, constant flow rate device in the connections


Characteristics

The flow meter consists of a spinner which is rotated by the flowing medium. The rotor's rotational speed is proportional to the flow volume per unit time. The rotor is fitted with stainless steel clamps (optionally titanium). An inductive proximity switch records the rotational speed, which is proportional to the flow rate.

Technical data

Sensor	inductive	
Nominal width	DN 10 (RRI-010)	
	DN 25 (RRI-025)	
Mechanical Connection	1	G 1 A 030
Pressure	PN 16	
resistance		
Medium temperature	060 °C	
Materials medium-contact	Housing	PPS, PVDF (Fortron 1140L4)
	Rotor	PVDF
	Clamps	1.4310 optionally: titanium
	Bearing	Iglidur X
	Axis	ceramic Zr0 ₂ -TZP
	Seal	FKM

Materials, non-	PVC cable, 1.4305, 1.4301,
medium-contact	CW614N nickelled
	O TTO T ITT THORESING
Current	10 mA / NAMUR max. 7 mA
consumption at	
rest	
Output current	200 mA / NAMUR max. 7 mA
max.	
Electrical	cable 2 m or for
connection	round plug connector M12x1, 4-pole
Sensor	, ,
Short circuit proof	ves
Reverse polarity	yes
protected	yes
!	
Ingress protection	IP 67
Weight	RRI-010 approx. 0.2 kg
	RRI-025 approx. 0.5 kg
Conformity	CE



- (1) Complete metering range
- (2) Specific metering range
- (3) Start-up range
- (4) Extended operating range, increased wear, Dp > 0.5 bar
- (5) Pulses / litre (details on label)
- (6) Average pulses / litre
- (7) Tolerance ±3 % of the measured value
- (8) Scatter ±10 % of the pulses / litre value (5) in the batch
- (9) Reproducibility (±1 % of the full scale value) is the repeat accuracy of a frequency, relative to I/min
- (10) Max. frequency, related to the relevant metering range up to approx. 0.5 bar pressure drop across the flow meter

Types	Q _{max}	Me	etering range	1	pulses / litre	frequency
RRI-	I/min H₂O		I/min H₂O			Hz EW
		(1)	(2)	(3)	(6)	(10)
010020	1.8	0.1 1.5	0.5 1.5	0.10.5	10200	255
010050	12.0	0.2 10.0	2.0 10.0	0.22.0	3345	558
010070	14.4	0.4 12.0	2.0 12.0	0.42.0	1755	351
025080	36.0	2.0 30.0	3.0 30.0	2.03.0	1216	608
025120	72.0	3.0 60.0	5.0 60.0	3.05.0	607	607
025160	120.0	4.0100.0	6.0100.0	4.06.0	252	420

The measured values were determined using a standing sensor in a horizontal flow of water at 25 °C.


Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.senseca.com | info@senseca.com | WEEE Reg. No. DE 93889386





Product Information

•


Wiring







Dimensions



Threaded connection

G	DN	Types	H/L	L1	В	С	E	F	F1	Х	SW
G 3/8	10	RRI-010G	50	84	29	12.5	16.5	32	60	12	22
G 3/8 A		RRI-010A								14	
G 1	25	RRI-025G	70	110	53	23.0	27.5	27	55	18	38
G 1 A		RRI-025A		122							
LIDT II					•						

NPT threads on request

Hose nozzle connection

D	DN	Types	H/L	L1	В	С	Е	F	F1	Х
Ø11	10	RRI-010T	50	96	11	12.5	16.5	32	60	21
Ø30	25	RRI-025T	70	176	30	23.0	27.5	27	55	45

Custom specific connectors on request

Handling and operation

The device is installed in the pipework with the aid of the rotatable adapter pieces. If necessary, the adapters can be removed from the body of the housing after the stainless steel clips have been removed from the housing. Before reinstalling, it should be ensured that both the adapter with the O-ring and the sealing surface in the body are clean and undamaged. The adapters should be fitted carefully in the housing (it is best to turn them), so that the O-ring is not damaged.

With this flow sensor, there is no need for run-in and run-out sections. However, it should be ensured that the flow sensor is at all times filled with medium. Any preferred installation position is possible, but the best possible venting position should be chosen (rotor axis horizontal, flow horizontal or from bottom to top). Air bubbles affect the measurement results. For filling processes,

the valve should be installed behind the sensor. A running up time of approx. 0.5 seconds and a running down time of approx. 3 seconds should be noted.

Ordering code

RRI-Q=Option 1. Nominal width 010 **DN 10** 025 **DN 25 Mechanical connection** 2. G female thread male thread Α hose nozzle **Connection material PVDF**

O PVDF V Α O PPS with transparent cover PSU 5. Inwards flow drilling 020 Ø2

O CW614N nickelled

O 1.4305

O EPDM

Housing material PPS

Κ

Q

F

	050	Ø 5		•
	070	Ø 7		•
	080	Ø 8	•	
	120	Ø12	•	
	160	Ø16	•	
6.	Seal mate	erial		
	V	FKM		

	N	\mathbf{O}	NBR
7.	Rotor		
	10		with 10 clamps
	02	0	with 2 clamps
	05	0	with 5 clamps
8.	Materia	al f	or clamps
	K		1.4310
	Т	0	titanium
9.	Signal	ou	tput

	P	PNP
	N	NPN o.C.
	C A	NAMUR
10.	Electrical	connection
10.	Electrical K	connection 2 m cable

Options

Rotor with titanium clamps

Accessories

- Cable/round plug connector (KB...) see additional information
- Mechanical connection pieces with non-return valve, filter, constant flow device or customer-specific requirements available on request